




Measures and mounting instruction for 0,37-2,2 kW drives



* **Minimum mounting distance** between inverter and other objects. All dimensions in mm

Measures and mounting instruction for 3-5,5 kW drives



* **Minimum mounting distance** between inverter and other objects. All dimensions in mm

Measures for 7,5-15 kW drives

